

## Rotel A11 / A11MKII RS232 ASCII Controller Command List

Date	Version	Update Description
December 18, 2018	1.00	Original Specification
June 7, 2024	1.10	Add A11MKII

The A11 and A11MKII supports an ASCII based RS232 protocol. The RS232 hardware does not support flow control so care needs to be taken when sending and receiving data to avoid packet loss.

All commands sent to the attached Rotel device must have a terminating “!” character.

Example Command: power on!

*Note: Do not include any spaces in the command, and do not include a carriage return or line feed after the command, only the “!” terminating character.*

Status information from the attached Rotel product will have a terminating “\$” character. It is up to the sending/receiving control application to properly parse and process the packets.

### Connection Settings

Baud Rate	Parity	Valid Data Bits	Stop Bit Value	Handshaking	Data Type
115200	N	8	1	None	String

### Communication Protocol

Command and response messages are included on the following pages. Automatic status update information can be enabled/disabled using the “rs232\_update\_on” and “rs232\_update\_off” commands.

With RS232 update set to ON, any status changes to the unit will be transmitted via RS232. With RS232 update set to OFF, the unit will not send any feedback unless polled by the controller.

## Section 1: Control Command List

A11/A11M KII ASCII	Command Description	Unit Response
<b>POWER &amp; VOLUME COMMANDS</b>		
Power_on!	Power On	power=on\$
Power_off!	Power Off	power=standby\$
power_toggle!	Power Toggle	power=on/standby\$
vol_up!	Volume Up	volume=##\$
vol_down!	Volume Down	volume=##\$
vol_nn!	Set Volume to level n (01 - 96)	volume=##\$
mute!	Mute Toggle	mute=on/off\$
mute_on!	Mute On	mute=on\$
mute_off!	Mute Off	mute=off\$
<b>SOURCE SELECTION COMMANDS</b>		
cd!	Source CD	source=cd\$
aux1!	Source Aux 1	source=aux1\$
tuner!	Source Tuner	source=tuner\$
phono!	Source Phono	source=phono\$
bluetooth!	Source Bluetooth	source=bluetooth\$
<b>SOURCE CONTROL COMMANDS</b>		
play!	Play Source	n/a
stop!	Stop Source	n/a
pause!	Pause Source	n/a
trkf!	Track Forward/Tune Up	n/a
trkb!	Track Backward/Tune Down	n/a
<b>TONE CONTROL COMMANDS</b>		
bypass_on!	Tone Bypass On	bypass=on\$
bypass_off!	Tone Bypass Off	bypass=off\$
bass_up!	Bass Up	bass=000/+##/-##\$
bass_down!	Bass Down	bass=000/+##/-##\$
bass_-10!	Set Bass to -10	bass=-10\$
bass_000!	Set Bass to 0	bass=000\$
bass_+10!	Set Bass to +10	bass=+10\$
treble_up!	Treble Up	treble=000/+##/-##\$
treble_down!	Treble Down	treble=000/+##/-##\$
treble_-10!	Set Treble to -10	treble=-10\$
treble_000!	Set Treble to 0	treble=000\$
treble_+10!	Set Treble to +10	treble=+10\$
<b>BALANCE CONTROL COMMANDS</b>		
balance_r!	Balance Right	balance=000/L##/R##\$
balance_l!	Balance Left	balance=000/L##/R##\$
balance_L15!	Set Balance to Max Left	balance=L15\$
balance_000!	Set Balance to 0	balance=000\$

A11/A11MKII ASCII	Command Description	Unit Response
balance_R15!	Set Balance to Max Right	balance=R15\$
<b>SPEAKER OUTPUT COMMANDS</b>		
speaker_a!	Toggle Speaker A Output	speaker=a/a_b/off\$
speaker_b!	Toggle Speaker B Output	speaker=b/a_b/off\$
speaker_a_on!	Speaker A Output On	speaker=a/a_b\$
speaker_a_off!	Speaker A Output Off	speaker=b/off\$
speaker_b_on!	Speaker B Output On	speaker=b/a_b\$
speaker_b_off!	Speaker B Output Off	speaker=a/off\$
<b>OTHER COMMANDS</b>		
dimmer!	Toggle display dimmer	dimmer=#\$
dimmer_0!	Set display to brightest setting	dimmer=0\$
dimmer_1!	Set display to dimmer level 1	dimmer=1\$
dimmer_2!	Set display to dimmer level 2	dimmer=2\$
dimmer_3!	Set display to dimmer level 3	dimmer=3\$
dimmer_4!	Set display to dimmer level 4	dimmer=4\$
dimmer_5!	Set display to dimmer level 5	dimmer=5\$
dimmer_6!	Set display to dimmest setting	dimmer=6\$
<b>RS232 FEEDBACK COMMANDS</b>		
rs232_update_on!	Set RS232 Update to Auto (On)	update_mode=auto\$
rs232_update_off!	Set RS232 Update to Manual (Off)	update_mode>manual\$

## Section 2: Feedback Request Command List

Command:	power?
Description:	Request current power status
Return String(s):	power=on\$ / power=standby\$
Return Description:	Current power status
Example:	power=on\$

Command:	source?
Description:	Request current source
Return String(s):	source=cd\$ / source=tuner\$ / source=phono\$ / source=aux1\$ / source=bluetooth\$
Return Description:	Current source
Example:	source= bluetooth\$

Command:	volume?
Description:	Request current volume value
Return String(s):	volume=##\$
Return Description:	2 digit current volume level
Example:	volume=40\$

Command:	mute?
Description:	Request current mute status
Return String(s):	mute=on\$ / mute=off\$
Return Description:	Current mute status
Example:	mute=off\$

Command:	bypass?
Description:	Request current tone bypass state
Return String(s):	bypass=on\$ / bypass=off\$
Return Description:	Current tone bypass state
Example:	bypass=off\$

Command:	bass?
Description:	Request current bass level
Return String(s):	bass=###\$ (+01-10, -01-10, 000)
Return Description:	Current tone control bass level
Example:	bass=+02\$

Command:	treble?
Description:	Request current treble level
Return String(s):	treble=###\$ (+01-10, -01-10, 000)
Return Description:	Current tone control treble level
Example:	treble=-01\$

Command:	balance?
Description:	Request current balance setting
Return String(s):	balance=###\$ (L01-15, R01-15, 000)
Return Description:	Current balance setting
Example:	balance=L03\$

Command:	speaker?
Description:	Request current active speaker outputs
Return String(s):	speaker=a\$ / speaker=b\$ / speaker=a_b\$ / speaker=off\$
Return Description:	Current active speaker outputs
Example:	speaker=a\$

Command:	dimmer?
Description:	Request current front display dimmer level
Return String(s):	dimmer=0\$ / dimmer=1\$ / dimmer=2\$ / dimmer=3\$ / dimmer=4\$ / dimmer=5\$ / dimmer=6\$
Return Description:	Current front display dimmer level
Example:	dimmer=3\$

Command:	version?
Description:	Request the main CPU software version
Return String:	version=#.##\$
Return Description:	Rotel main CPU software version
Example:	version=1.09\$

Command:	model?
Description:	Request the model number
Return String:	model=text\$
Return Description:	Rotel model number
Example:	model=a11\$