



## Rotel RCX-1500 RS232 ASCII Controller Command List

Date	Version	Update Description
January 18, 2012	1.00	Original Specification
October 9, 2012	1.01	Added memory command
March 1, 2013	1.02	Added discrete opt/coax input & power status commands. Requires Main Software V1.1.7
December 26, 2013	1.10	Added dimmer + CD player scan commands
June 4, 2014	1.20	Added special character mapping
August 28, 2018	1.21	Add missing "!" char to recall preset commands.

Rotel has released updated software for RCX-1500. The new software includes an ASCII based RS232 protocol. The new protocol replaces the original HEX based communication protocol. This new protocol is ASCII text based to make it easier for application programmers to communicate with Rotel products.

The new protocol is effective starting with the Main software version V1.1.5.

The new protocol eliminates the Device ID and checksum requirements. The RS232 hardware does not support flow control so care needs to be take when sending and receiving data to avoid packet loss.

All commands sent to the attached Rotel device must have a terminating "!" character . Status information from the attached Rotel product with either have a terminating "!" character or a byte count for variable length text data that may include a "!" in the returned message. It is up to the sending/receiving control application to properly parse and process the packets.

*Note: The byte count only includes the text data and not the length or " ," character.*

*Note 2: Do not include a carriage return or line feed after the command, only the "!" terminating character.*

### Connection Settings

Baud Rate	Parity	Valid Data Bits	Stop Bit Value	Handshaking	Data Type
115200	N	8	1	None	String

### Communication Protocol

Command and response messages are included on the following pages. Automatic display update information can be enabled/disabled using the "display\_update\_auto" and "display\_update\_manual".

In automatic mode each time the display changes the new display line(s) will be sent.

In manual mode the display updates must be requested each time a refresh of the display information is desired.

## Section 1: Control Command List

RCX-1500 ASCII	Command Description	Unit Response
<b>POWER &amp; VOLUME COMMANDS</b>		
power_on!	Power On	power=on!
power_off!	Power Off	power=standby!
power_toggle!	Power Toggle	power=on/standby!
volume_up!	Volume Up	volume=##!
volume_down!	Volume Down	volume=##!
volume_max!	Set Volume to Max	volume=max!
volume_min!	Set Volume to Min	volume=min!
volume_n!	Set Volume to level n (n = 1 - 86)	volume=##!
mute!	Mute Toggle	mute=on/off!
mute_on!	Mute On	mute=on!
mute_off!	Mute Off	mute=off!
<b>SOURCE SELECTION COMMANDS</b>		
cd!	Source CD	source=cd!
iradio!	Source iRadio	source=iradio!
network!	Source Network	source=network!
aux1_coax!	Source Aux 1 Coax	source=aux1_coax!
aux1_opt!	Source Aux 1 Optical	source=aux1_opt!
aux2!	Source Aux 2	source=aux2!
fm!	Source FM	source=fm!
dab!	Source DAB	source=dab!
usb!	Source USB	source=usb!
aux1!	Source Aux 1 Coax/Opt Toggle	source=aux1_coax! / source=aux1_opt!
<b>SOURCE CONTROL COMMANDS</b>		
play!	Play Source	play_status=play!
stop!	Stop Source	play_status=stop!
pause!	Pause Source	play_status=pause!
track_fwd!	Track Forward / Tune Up	track=##, T##
track_back!	Track Backward / Tune Down	track=##, T##
fast_fwd!	Fast Forward / Search Forward	time=##:##:##!
fast_back!	Fast Backward / Search Backward	time=##:##:##!
eject!	Eject CD	eject_status=open/close!
random!	Random Play Mode Toggle	n/a
repeat!	Repeat Play Mode Toggle	n/a
<b>MENU CONTROL COMMANDS</b>		
menu!	Display the Menu	n/a
exit!	Exit Key	n/a
up!	Cursor Up	n/a
down!	Cursor Down	n/a
left!	Cursor Left	n/a

RCX-1500 ASCII	Command Description	Unit Response
right!	Cursor Right	n/a
enter!	Enter Key	n/a
enter_long!	Long Press for Enter Key	n/a
<b>NUMERIC KEY COMMANDS</b>		
1!	Number Key 1	n/a
2!	Number Key 2	n/a
3!	Number Key 3	n/a
4!	Number Key 4	n/a
5!	Number Key 5	n/a
6!	Number Key 6	n/a
7!	Number Key 7	n/a
8!	Number Key 8	n/a
9!	Number Key 9	n/a
0!	Number Key 0	n/a
10_plus!	Number Key 10+	n/a
<b>FM / DAB / IRADIO PRESET COMMANDS</b>		
memory!	Select memory for saving presets	n/a
call_iradio_preset_n!	Recall iRadio Preset n (n = 01 - 30)	iradio_preset_n=##,text
call_fm_preset_n!	Recall FM Preset n (n = 01 - 30)	fm_preset_n=##,text
call_dab_preset_n!	Recall DAB Preset n (n = 01 - 30)	dab_preset_n=##,text
<b>OTHER COMMANDS</b>		
scan!	CD Title Scan	n/a
time!	Toggle CD Time Display	n/a
dimmer!	Toggle Display Dimmer	dimmer_#!
<b>DISPLAY REFRESH COMMANDS</b>		
display_update_auto!	Set Display Update to Auto	display_update=auto!
display_update_manual!	Set Display Update to Manual	display_update=manual!

## Section 2: Feedback Request Command List

<b>Command:</b>	get_display!
<b>Description:</b>	Request the entire display to be sent
<b>Return String:</b>	display=###,text
<b>Return Description:</b>	Current display data; must include 3 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	display=080, Sample Text

<b>Command:</b>	get_display1!
<b>Description:</b>	Request display line #1 to be sent
<b>Return String:</b>	display1=##,text
<b>Return Description:</b>	Current display line 1, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	display1=20, Sample Text

<b>Command:</b>	get_display2!
<b>Description:</b>	Request display line #2 to be sent
<b>Return String:</b>	display2=##,text
<b>Return Description:</b>	Current display line 2, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	display2=20, Sample Text

<b>Command:</b>	get_display3!
<b>Description:</b>	Request display line #3 to be sent
<b>Return String:</b>	display3=##,text
<b>Return Description:</b>	Current display line 3, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	display3=20, Sample Text

<b>Command:</b>	get_display4!
<b>Description:</b>	Request display line #4 to be sent
<b>Return String:</b>	display4=##,text
<b>Return Description:</b>	Current display line 4, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	display4=20, Sample Text

<b>Command:</b>	get_product_type!
<b>Description:</b>	Request the product type
<b>Return String:</b>	product_type=##,text
<b>Return Description:</b>	Rotel product type name, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	product_type=08,RCX-1500

<b>Command:</b>	get_product_version!
<b>Description:</b>	Request the main CPU software version
<b>Return String:</b>	product_version=##,text
<b>Return Description:</b>	Rotel main CPU software version, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	product_version=13,v1.1.2-110316

<b>Command:</b>	get_display_size!
<b>Description:</b>	Request display size
<b>Return String:</b>	display_size=##,##!
<b>Return Description:</b>	Columns and rows on current display
<b>Example:</b>	display_size=20,04!

<b>Command:</b>	get_display_update!
<b>Description:</b>	Request display update
<b>Return String(s):</b>	display_update=auto! / display_update=manual!
<b>Return Description:</b>	Status of if the display refresh is automatic or manual
<b>Example:</b>	display_update=auto!

<b>Command:</b>	get_current_power!
<b>Description:</b>	Request current power status
<b>Return String(s):</b>	power=on! / power=standby!
<b>Return Description:</b>	Current power status
<b>Example:</b>	power=on!

<b>Command:</b>	get_current_source!
<b>Description:</b>	Request current source
<b>Return String(s):</b>	source=cd! / source=iradio! / source=network! / source=aux1! / source=aux2! / source=usb! / source=fm! / source=dab!
<b>Return Description:</b>	Current source
<b>Example:</b>	source=cd!

<b>Command:</b>	get_current_preset!
<b>Description:</b>	Request current preset
<b>Return String(s):</b>	preset_iradio=###! / preset_fm=###! / preset_dab=###!
<b>Return Description:</b>	Current preset station 2 digit length
<b>Example:</b>	preset_iradio=13!

<b>Command:</b>	get_iradio_preset_n!
<b>Description:</b>	Request saved iRadio station info for present n (n = 1 – 30)
<b>Return String(s):</b>	iradio_preset_n=##,text
<b>Return Description:</b>	Saved iRadio preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	iradio_preset_02=##,text

<b>Command:</b>	get_allpreset_iradio!
<b>Description:</b>	Request all saved iRadio station info [ 1..30 ]
<b>Return String(s):</b>	iradio_preset_n=##,text
<b>Return Description:</b>	Saved iRadio preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	iradio_allpreset_01=##,text .. iradio_allpreset_30=##,text

<b>Command:</b>	get_fm_preset_n!
<b>Description:</b>	Request saved FM station info for present n (n = 1 – 30)
<b>Return String(s):</b>	fm_preset_n=##,text
<b>Return Description:</b>	Saved FM preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	fm_preset_04=##,text

<b>Command:</b>	get_allpreset_fm!
<b>Description:</b>	Request all saved FM station info [ 1..30 ]
<b>Return String(s):</b>	fm_preset_n=##,text
<b>Return Description:</b>	Saved FM preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	fm_allpreset_01=##,text .. fm_allpreset_30=##,text

<b>Command:</b>	get_dab_preset_n!
<b>Description:</b>	Request saved DAB station info for present n (n = 1 – 30)
<b>Return String(s):</b>	dab_preset_n=##,text
<b>Return Description:</b>	Saved DAB preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	dab_preset_01=##,text

<b>Command:</b>	get_allpreset_dab!
<b>Description:</b>	Request all saved DAB station info [ 1..30 ]
<b>Return String(s):</b>	dab_preset_n=##,text
<b>Return Description:</b>	Saved DAB preset number, must include 2 digit length of text string at beginning followed by "," and text string (no terminating character)
<b>Example:</b>	dab_allpreset_01=##,text .. dab_allpreset_30=##,text

<b>Command:</b>	get_cd_tray_status!
<b>Description:</b>	Request CD tray status
<b>Return String(s):</b>	eject_status=open! / eject_status=close! / eject_status=loading!
<b>Return Description:</b>	CD Tray status
<b>Example:</b>	eject_status=open!

<b>Command:</b>	get_cd_play_status!
<b>Description:</b>	Request CD play status
<b>Return String(s):</b>	play_status=play! / play_status=stop! / play_status=pause!
<b>Return Description:</b>	CD Play status
<b>Example:</b>	play_status=pause!

<b>Command:</b>	get_play_status!
<b>Description:</b>	Request play status (non CD source playback)
<b>Return String(s):</b>	play_status=play! / play_status=stop! / play_status=pause!
<b>Return Description:</b>	Source play status
<b>Example:</b>	play_status=play!













<b>Command:</b>	get_volume!
<b>Description:</b>	Request current volume value
<b>Return String(s):</b>	volume=##!
<b>Return Description:</b>	2 digit current volume level
<b>Example:</b>	volume=40!

<b>Command:</b>	get_volume_max!
<b>Description:</b>	Request Max volume value
<b>Return String(s):</b>	volume_max=##!
<b>Return Description:</b>	2 digit volume max level
<b>Example:</b>	volume_max=80!

<b>Command:</b>	get_volume_min!
<b>Description:</b>	Request Min volume value
<b>Return String(s):</b>	volume_min=0!
<b>Return Description:</b>	volume min level
<b>Example:</b>	volume_min=0!

### Section 3: Special Character Mapping

Certain characters on the RCX-1500 display may be represented by a combination of 2-3 hex bytes in the feedback string provided by the unit. Refer to the chart below for a mapping of the different characters.

Symbol	Hex Value	Symbol	Hex Value	Symbol	Hex Value
<b>A</b>	EE 82 85	<b>D</b>	EE 82 8A		EE 82 99
<b>C</b>	EE 82 84		EE 82 8B		EE 82 9A
<b>F</b>	EE 82 92	<b>  </b>	EE 82 81		EE 82 88
<b>G</b>	EE 82 87		EE 82 82		EE 82 95
<b>I</b>	EE 82 8E		EE 82 83		EE 82 96
<b>L</b>	EE 82 89		EE 82 94	*	EE 82 90
<b>M</b>	EE 82 93		EE 82 97		EE 82 91
<b>R</b>	EE 82 8C		EE 82 98	<b>Z</b>	EE 82 8D
<b>S</b>	EE 82 8F	<b>T</b>	EE 82 80	END	EE 80 80 EE 80 81 EE 80 82